



- ① Connect Studio cable
- ② Swap padding



- ③ Activate Hi-Fi mode
- ④ 4.4 mm Hi-Fi cable

H715
Reference

Quick Start Guide

 ADAM AUDIO